

OMNI 3200 QUICK REFERENCE GUIDE

VSYR022 (SOFTPAY)
RESTAURANT
ETC TYPE 7 APPLICATION



Credit Sale

1 Press F2 key on the Terminal.

If debit is activated, choose **CREDIT** when prompted to select sale type.

Manually enter card information.

- Key in card number and press **ENTER**.
- Key in card expiration date and press **ENTER**.
(Example: for December 2001, enter 1201)

2 Swipe card through vertical slot as shown on terminal*

NOTE: Prompting messages vary based on card type and setup. Terminal may display the following prompts:

- Invoice Number? Key the appropriate information, press **ENTER**.
- Server ID? Key the appropriate information, press **ENTER**.

3 Key in dollar amount of transaction, then press ENTER.

- Miscellaneous Amount? Key the appropriate information, press **ENTER**.
- Tip Amount? Key the appropriate information, press **ENTER**.
- Print Customer Copy? Press **F2** for yes, **F1** for no.

4 Transaction complete.

Terminal displays transaction response (see "Response Codes" below). Receipt prints if transaction is approved.

- **Have customer sign receipt and place in cash register drawer.**

Credit Return/Refund

1 Press F3 key on the terminal.

If debit is activated, choose **CREDIT** when prompted to select refund type.

Manually enter card information.

- Key in card number and press **ENTER**.
- Key in card expiration date and press **ENTER**.
(Example: for December 2001, enter 1201)

2 Swipe card through vertical slot as shown on terminal*.

NOTE: Prompting messages vary based on card type and setup. Terminal may display the following prompts:

- Invoice Number? Key the appropriate information, press **ENTER**.
- Server ID? Key the appropriate information, press **ENTER**.

3 Key in dollar amount of transaction, then press ENTER.

- Miscellaneous Amount? Key the appropriate information, press **ENTER**.
- Tip Amount? Key the appropriate information, press **ENTER**.
- Print Customer Copy? Press **F2** for yes, **F1** for no.

4 Transaction complete - Return/Refund captured.

After Return/Refund is captured, terminal prints copy of Return/Refund voucher.

- **Have customer sign receipt and place in cash register drawer.**

Credit Ticket Only

When given an approval code by an operator, you must complete a Credit Ticket Only transaction to enter item into terminal and print receipt for customer to sign.

1 Press ↓ key on the terminal then press F1 to select Ticket Only.

Manually enter card information.

- Key in card number and press **ENTER**.
- Key in card expiration date and press **ENTER**.
(Example: for December 2001, enter 1201)

2 Key in dollar amount of transaction, then press ENTER.

NOTE: Prompting messages vary based on card type and setup. Terminal may display the following prompts:

- Invoice Number? Key the appropriate information, press **ENTER**.
- Server ID? Key the appropriate information, press **ENTER**.

3 Key in dollar amount of transaction, then press ENTER.

- Miscellaneous Amount. Key the appropriate information, press **ENTER**.
- Tip Amount? Key the appropriate information, press **ENTER**.
- Auth Code? Key the appropriate information, press **ENTER**.
- Print Customer Copy? Press **F2** for yes, **F1** for no.

Debit Sale

1 Press F2 key on the terminal.

2 Swipe card through vertical slot as shown on terminal.

(All debit card transactions must be swiped; debit card numbers may not be entered manually.)

- Choose **DEBIT** when prompted to select Sale type.
- Server ID? Key the appropriate information, press **ENTER**.

3 Key in Debit Sale amount and press ENTER.

NOTE: Prompting messages vary based on card type and setup. Terminal may display the following prompts:

- Misc. Amount? Key the appropriate information, press **ENTER**.
- Tip Amount? Key the appropriate information, press **ENTER**.
- Cash Back? Key the appropriate information, press **ENTER**.

4 Customer enters PIN to complete transaction.

Customer must key in private Personal Identification Number and press **ENTER** on PIN pad.

- Print Customer Copy? Press **F2** for yes, **F1** for no.

5 Transaction complete.

Terminal displays transaction response (see "Response Codes" below). Receipt prints if transaction is approved.

- **Have customer sign receipt and place in cash register drawer.**

Debit Return/Refund

1 Press F3 key on the terminal.

2 Swipe card through vertical slot as shown on terminal.

(All debit card transactions must be swiped; debit card numbers may not be manually entered.)

- Choose **DEBIT** when prompted to select Sale type.
- Server ID? Key the appropriate information, press **ENTER**.

3 Key in debit refund amount and press ENTER.

NOTE: Prompting messages vary based on card type and setup. Terminal may display the following prompts:

- Misc. Amount? Key the appropriate information, press **ENTER**.
- Tip Amount? Key the appropriate information, press **ENTER**.

4 Customer enters PIN to complete transaction.

Customer must key in private Personal Identification Number and press **ENTER** on PIN pad. Give customer a copy of the refund slip.

- Print Customer Copy? Press **F2** for yes, **F1** for no.

Terminal Responses

▶ Definitions:

- **Call Center**
 - Operator should call the credit authorization center.
- **Declined**
 - The authorization for the transaction has been declined.
- **Invalid Card #**
 - The credit card presented is not acceptable for payment.
- **Invalid Tran Type**
 - Incorrect transaction attempted.
- **Invalid Merch #**
 - Invalid merchant # for the transaction attempted.
- **Invalid Amount**
 - Authorization request must be for at least \$1.00.
- **Inv Batch Seq**
 - Improper procedures have created an invalid terminal condition.
- **Force \$XXXXX.XX**
 - The batch was closed with an error condition.
- **Invalid \$XXXXX.XX**
 - An invalid cardholder # was detected in the batch during the close process.
- **Close \$XXXXX.XX**
 - The response for a normal close transaction.

Card Name	Merchant Number	Phone Number
-----------	-----------------	--------------

Amex:

Diners:

Discover:

VISA/MC:

Customer Support:

Additional Terminal Functions

▶ Tip Adjust.

Press **TIP ADJUST** key on the terminal.

- Enter **PASSWORD**.

Terminal Displays Retrieve By:

Srvr	F1
Amt	F2
Acct	F3
Inv#	F4

Select appropriate option

Terminal Displays:

Tran Type	Adj	F1
Card#	Next	F2
Amt		

Select appropriate option

- If Adjust, adjust the tip amount, press **ENTER**.
- If Next, next transaction displays for edit.

▶ Void a Credit Transaction.

Press **F4** key on the terminal.

- Void Last Transactions. Press **F1** for no, **F2** for yes.

A. If no,

Terminal Displays Retrieve By:

Inv #	F1
Acct #	F2

Select appropriate option.

Terminal Displays Retrieve By:

Card #	No	F1
Amount #	Yes	F2
	Next	F3

Select appropriate option.

- If no, transaction will be cancelled, press CLEAR.
- If yes, refer to step B.
- If next, terminal displays next item to be voided. (Refer to steps A or B)
- B. If yes, transaction will be voided.
- Print Customer Copy? Press **F2** for yes, **F1** for no.

▶ Settlement.

Press **↓** key until desired option appears.

Terminal Displays:

Sales: \$0.00
Refunds \$0.00
Total: \$0.00

Enter to confirm

- Press **ENTER** to confirm.

▶ Batch Review.

Press **↓** key until desired option appears.

- Enter **PASSWORD**.

Terminal Displays Retrieve By:

Press **F1** for Srvr, **F2** for Amt, **F3** for Acct or **F4** for Inv#.

- If Srvr, key in the clerk ID and press **ENTER**.
- If Amt, key in the total transaction amount and press **ENTER**.
- If Acct, key in the last 5 digits and press **ENTER**.
- If Inv#, key in the invoice # and press **ENTER**.

For each option selected terminal displays:

Tran Type	Adj	F1
Card#	Prnt	F2
Amt	Void	F3
	Next	F4

- If Adj, adjust by:

F1 for Amt, **F2** for tip, **F3** for clerk, or **F4** for Appv. (select an option and key in the appropriate data, press **ENTER**)

NOTE:If amt or tip selected adjust trans.

- If Prnt, terminal will print a duplicate receipt.
- If Void, terminal will void selected transaction.
- If Next, terminal will display next transaction.

▶ View Batch Totals.

Press **↓** key until desired option appears.

Terminal Displays Retrieve By:

Sales: \$0.00
Returns: \$0.00
Totals: \$0.00

▶ Reprint Receipt.

Press **F1** for last receipt, **F2** for any receipt.

- If any receipt, key in invoice# and press **ENTER**.